

BoXo – Belegungsplan

Speakon 4pol 2-fach Splitter (U3630)

IN 1	NL4MP	1+	1-	2+	2-
OUT 1	NL4MP	1+	1-	2+	2-
OUT 2	NL4MP	1+	1-	2+	2-

Speakon 4pol 2-fach Verteiler (U3631)

IN 1	NL4MP	1+	1-	2+	2-
OUT 1	NL4MP	1+	1-		
OUT 2	NL4MP			2+	2-

Speakon 4pol 3-fach Splitter (U3632)

IN 1	NL4MP	1+	1-	2+	2-
OUT 1	NL4MP	1+	1-	2+	2-
OUT 2	NL4MP	1+	1-	2+	2-
OUT 3	NL4MP	1+	1-	2+	2-

Speakon / 1/4“ Klinkenbuchsen 2-Kanal Adapter (U3633)

IN 1	NL4MD	1+	1-
OUT 1	NL4MD	1+	1-
IN 2	NL4MD	1+	1-
OUT 2	NL4MD	1+	1-

Speakon / 1/4“ Klinkenbuchsen 3-fach Splitter (U3634)

IN 1	NL4MD	1+	1-
OUT 1	NL4MD	1+	1-
OUT 2	NL4MD	1+	1-
OUT 3	NL4MD	1+	1-

Speakon 8pol auf 2x 4pol Adapter (U3640)

IN 1	NL8MD	1+	1-	2+	2-	3+	3-	4+	4-
OUT 1	NL4MD	1+	1-	2+	2-				
OUT 2	NL4MD					1+	1-	2+	2-

Speakon 8pol auf 1x 8pol und 4x 4pol Adapter (U0101)

IN 1	NL8MD	1+	1-	2+	2-	3+	3-	4+	4-
OUT 1	NL4MD	1+	1-						
OUT 2	NL4MD			1+	1-				
OUT 3	NL4MD					1+	1-		
OUT 4	NL4MD							1+	1-

Speakon 8pol auf 1x 8pol und 4x 4pol Adapter (U8801)

IN 1	NL8MD	1+	1-	2+	2-	3+	3-	4+	4-
OUT 1	NL8MD	1+	1-	2+	2-	3+	3-	4+	4-
OUT 1	NL4MD	1+	1-						
OUT 2	NL4MD			1+	1-				
OUT 3	NL4MD					1+	1-		
OUT 4	NL4MD							1+	1-

8pol Lautsprecher Adapter-Kabel (U0099)

IN 1	NLT8MX	1+	1-	2+	2-	3+	3-	4+	4-
OUT 1	SPK08MP	A	B	C	D	E	F	G	H

8pol Lautsprecher Adapter-Kabel (U0098)

IN 1	NLT8FX	1+	1-	2+	2-	3+	3-	4+	4-
OUT 1	SPK08FP	A	B	C	D	E	F	G	H

Speakon 4pol auf Bananenbuchse Tester

IN 1	NL4MP	1+	1-	2+	2-
OUT 1	NL4MP	1+	1-	2+	2-

Die Belegungen können je nach Kundenwunsch variieren.

Stand: 11/2012